



## Sunroof water drain hoses, cleaning

### **Note:**

*For cleaning, a locally manufactured tool made from a speedometer inner cable, approx. 2300 mm (90.5 in.) long is recommended.*

### **1 - Front water drain hoses**

- ◆ Routed in A-pillars and exits between door and A-pillar. Can be cleaned from sunroof cut-out

### **2 - Rear water drain hoses**



A60-0050

- ◆ Routed in C-pillars and exits behind bumper cover at side. Can be cleaned from lower end of hose. To do so, rear bumper cover must be removed ⇒ [Page 63-42](#) .